


# AIRPORT DIAGRAM

AL-432 (FAA)

TULSA INTL (TUL)  
TULSA, OKLAHOMA


TULSA TOWER  
 121.2 310.8 RWYS 18L-36R, 8-26  
 118.7 257.8 RWY 18R-36L  
 GND CON  
 121.9 348.6  
 CLNC DEL  
 134.05 284.7



JANUARY 1995  
 ANNUAL RATE OF CHANGE  
 0.1° W

SC-1, 01 SEP 2005 to 29 SEP 2005

SC-1, 01 SEP 2005 to 29 SEP 2005



RWY 8-26  
 S75, T200, ST175, TT360  
 RWY 18L-36R  
 S75, T200, ST175, TT400  
 RWY 18R-36L  
 S60, T100

CAUTION: BE ALERT TO RUNWAY  
 CROSSING CLEARANCES.  
 READBACK OF ALL RUNWAY HOLDING  
 INSTRUCTIONS IS REQUIRED.

# AIRPORT DIAGRAM

TULSA, OKLAHOMA  
TULSA INTL (TUL)